

ATEX Airlamp Model numbers A-TL45B A-TL44B, A-TL45A and A-TL44A

In order to inspect and maintain the Airlamps the rear cover must be removed. See Maintenance instruction for assembly break down. When the three housing cover screws (A-18) have been removed the cover will need to be removed with the help of light tapping with a plastic or hide mallet. This is because the bearing in the generator housing has an adhesive on the outer ring. Do not use a tool to prise cover as this may damage castings.



When reassembling the lamp ensure the bearing outer race and the generator housing bearing bore are clean. DO NOT USE abrasive cleaners. A small amount of loctite 222 or equivalent thread-locking adhesive should be applied to the generator housing bearing bore.

